



# Swirl Frozen Drinks

## Daily Operation Instructions

- Maintain drink level between minimum and maximum levels at all times.
- Wipe any drink splatter from machine with damp wet cloth.
- Empty and rinse drip trays.
- Refer to diagram for switch setting. →

All switches are in the up position to serve frozen drinks.



Top 2 switches are in the down position at night or when not serving drinks.

Bottom 4 switches are in the up position at all times.